



Technical parameters

Detection range: 60...1000mm
 Adjustment range: 70...1000mm
 Blind spots: 0...60mm
 Standard detection plate: 100×100mm
 Angle: ±7°
 Sensor frequency: Approx. 200 kHz
 Response delay: ≤100ms
 Operating voltage: 9...30V DC, 10%Vpp
 No-load current: ≤35mA
 LED green light: Constant light: Turn on the power
 LED blue light: Constant light: Can be learned (5 minutes before powering on), Flashing: Enter the learning state
 LED yellow light: Solid on: Switch status indication, Flashing: The learning state detects the target
 LED red light: Solid Light: The learning state does not detect the target, Flickering: Error occurred

Infusion

Enter the form: A1, learning wire-UB; A2, learning wire connection + UB

lose

Output method: PNP
 Rated working current: 200mA, short-circuit protection/overload protection
 Default settings: Normally open window mode, A1=60mm; A2=1000mm
 Repeatability: ±1% of full-scale value
 Hysteresis range: 1% of the set switching distance
 Temperature drift: ±2% of full-scale value (built-in temperature compensation)

Characteristics

Operating temperature: -25° C... 70° C
 Storage temperature: -40° C... 85° C
 Electromagnetic compatibility: GB/T17626.2-2006, GB/T17626.4-2008

Protection level: IP67

Connection: V1 connector (M12×1), 4 pins

Shell material: Brass nickel plated

Transducers: Plastic, epoxy resin + glass beads


Weight: Approx. 46g

Product Model: ISUB1000-18GM75-E5-V1 View Details


Ultrasonic sensor

- PNP output
- You can learn A1/A2 points
- Temperature compensation
- Small blind spots
- Serial port upgrade


Electrical connections



Dimensions



Response characteristic curve




mm

Test conditions: power supply 24V, 25° C, humidity 50%, actual deviation, for reference only

Set the detection range

Working mode: A1 and A2 can be learned separately, by setting the position of A1 point and A2 point, you can choose the working mode, there are 5 working modes in total:



Note: Distance A1 or A2 → ∞ indicates that no target was detected during learning.

First, the sensor is powered on, and the green indicator light on the back of the sensor will light up

Set A2 points:

1) Place a test object where the distance needs to be set; 2) Connect the learning cable and the power supply positively, the blue light flashes all the time to indicate that it has entered the learning state, during this period, if the test object is captured, the yellow light flashes, this state lasts for 2 to 3 seconds, then disconnect the learning cable (**note that do not cut off the power within 2 seconds after disconnecting the learning line, otherwise the setting may fail**), A2 setting is successful, if the target is not detected during the setting period, the red light will turn on;

Set A1 point:

1) Place a test object where the distance needs to be set;
 2) Connect the learning cable negatively to the power supply and repeat the above steps;

Note: The learning mode can only be learned within 5 minutes of power-up

Installation

Since ultrasonic sensors are directional, attention needs to be paid to the installation position. It is recommended that the mounting position and the DUT be perpendicular for better relative accuracy

Notes:

- 1) The temperature drift is mainly due to the heating of the sensor at the beginning of the electric power, resulting in the temperature measurement bias inside the sensor, which in turn leads to the ranging deviation, which reaches stability after about half an hour.
- 2) Do not input voltages other than the normal operating voltage to avoid sensor burnout failure.
- 3) Do not wire incorrectly to avoid sensor burnout failure.
- 4) Avoid pulling the sensor lead wire too hard to prevent damaging the sensor's electrical connection.
- 5) It is forbidden to cover the surface of the sensor probe to avoid affecting the detection range of the sensor.
- 6) The sensor should avoid strong mechanical vibration when used, and the working environment should not have strong electromagnetic interference and rapid air circulation.
- 7) Please do not disassemble the sensor without permission, if the sensor does not work properly, please contact the after-sales service in time to solve it, the company will not be responsible for all the consequences caused by unauthorized disassembly.